



LOUDSPEAKER ARRANGEMENT



FRONT FILL SPEAKERS



SURROUND SPEAKERS

<NOTE>

PROSCENIUM		MEYER SOUND	MSL-4	6EA
		MEYER SOUND	CQ-1	9EA
		MEYER SOUND	650-P	4EA
SURROUND	LEFT	STAGE ACCOMPANY F-7		10EA
	RIGHT	STAGE ACCOMPANY F-7		10EA
	REAR	STAGE ACCOMPANY F-7		8EA
FRONT FILL	APRON	STAGE ACCOMPANY F-7		8EA
	FORESTAGE	STAGE ACCOMPANY F-7		10EA
	2nd UNDER BALCONY	STAGE ACCOMPANY F-7		6EA
	1st UNDER BALCONY	STAGE ACCOMPANY F-7		6EA

LG ARTS CENTER SOUND SYSTEM

TITLE
DATE
COMPANY
PRODUCER

SCALE
DESIGNER
REMARK

NON SCALE